

ASSEMBLY AND INSTRUCTION MANUAL MODEL 0618 BOOGIE

© 2018 KURT BEIER & KATI QUINGER





Swing function




360° rotary system




Attention! Safety note:

The base plate is plugged into a conical turning spindle. For transportation it is absolutely necessary to lift up the chair at the base plate.




Turning and swing system

360 ° Rotary system:



Swing system:



Attention! Maximum load of turning and swing system: up to 110 kg